

**EASY-AS-CAN-BE ASSEMBLY!**


**Your kite is partially assembled, so you'll be flying in no time!**

1. Insert the loose strut between the pockets on the back of kite.
2. Tie a knot to attach the kite line to a loop on the keel on the front of the kite. Use the lower loop in stronger winds and the upper loop in a lighter breeze.
3. Unfurl the tails when you are ready to launch!  
Two tails will help keep the kite steadier in stronger winds.

**KITE-FLYING TIPS**

**Follow these simple steps to get your kite soaring safely!**

- Choose a location with plenty of space to fly your kite. The ground should be level and flat.
- This kite works best in a light to moderate breeze—Beaufort Number 2-4 (see chart below).
- It's easiest to have someone help you launch the kite. Stand with your back to the wind; helper faces into the wind.
- Let out about 20-25 feet (6-7.6 meters) of the flying line while the helper holds the kite facing upward at head height. Stand farther apart in a lighter breeze, closer together in stronger wind.
- When the line is taut, signal the helper to release the kite.
- When the kite is airborne and stable, let out some line until the kite begins to drop. Pull the line taut until the kite rises higher in the sky.
- Repeat until the kite has reached the best height for wind conditions.



**PRECAUTIONS/WARNINGS**

- Do not fly kite near overhead cables, wires, or transmission towers. If kite is accidentally caught in power lines, never attempt to dislodge it yourself. Contact relevant authorities for help.
- Do not fly kite near an airport.
- Do not fly kite in wet or stormy weather.
- Never fly kite over other people's heads or over roads or parking lots.
- Always use a line holder. Never hold the line by itself or let the line run through your hands; do not loop or tie line around your fingers.
- If kite gets out of control in a high wind, it's best to cut the line and let it go—better to lose the kite than to cause any damage.
- It's always worth writing your name and address or phone number on your kite, just in case one day it decides to take off without you!

*Kite flying is endless fun, but requires thoughtful consideration. Be a responsible kite flyer—always be aware of your surroundings and put safety first!*

**Beaufort Scale**

BEAUFORT #	MPH	KM/H	KNOTS	TERMINOLOGY	DESCRIPTION
0	0-1	0-1	0-1	CALM	Smoke rises vertically
1	1-3	1-5	1-3	LIGHT AIR	Smoke drifts with air
2	4-7	6-11	4-6	LIGHT BREEZE	Weather vanes moved by wind; leaves rustle
3	8-12	12-19	7-10	GENTLE BREEZE	Leaves and small twigs in constant motion; light flags extended
4	13-18	20-28	11-16	MODERATE BREEZE	Small branches sway
5	19-24	29-38	17-21	FRESH BREEZE	Small trees sway
6	25-31	38-49	22-27	STRONG BREEZE	Large branches sway; umbrellas used with difficulty

**Ages 3+**

Wind Runner Cutter Kite #30211

MADE IN CHINA

PDC

Melissa & Doug®

We ♥ feedback! Call us: 1-800-284-3948  
MelissaAndDoug.com

Melissa & Doug products meet or exceed U.S. testing standards and pass our high quality requirements.

© Melissa & Doug, LLC, P.O. Box 590, Westport, CT 06881

**WARNING:**  
Do not use near overhead power lines or during thunderstorms.

**WARNING:**  
Strangulation hazard. Long cord.

Remove all packaging before giving the product to a child.

Please retain for information.